




FORESTER FRONT GRILLE  
FORESTER FRONT GITTER  
FORESTER GRILLE AVANT  
FORESTER GRATA ANTERIORE ▪  
FORESTER LA VERJA DELANTERA


INSTALLATION INSTRUCTION  
EINBAUANLEITUNG  
INSTRUCTIONS DE L'INSTALLATION  
ISTRUZIONI USO ▪  
INSTRUCCIONES PARA LA INSTALACION  
(2008.January)

PART.No

J1010SC100##



①



②

